


Como conectar tu Chromebook al Wi-Fi

Antes de que puedas conectarte al Wi-Fi, tendras que habilitarlo. Aqui se explica como hacerlo.

1. En la esquina inferior derecho de la pantalla, haga clic en el area con el simbolo de Wi-Fi (si no esta habilitado, vera un contorno sin senal disponible en el interior).
2. Haga un clic en “ Not Connected” vera que se active el boton de Wi-Fi y buscara automaticamente las redes locales.




Click on "Not connected" to search for Wi-Fi networks. Devon Delfino/Business Insider

3. Si ya ha establecido una conexion Wi-Fi local, deberia conectarse automaticamente.



Click on the Wi-Fi icon with a plus sign if you don't see your network. Devon Delfino/Business Insider

4. Ingrese el SSID de la red a la que desea unirse, luego ingrese la contraseña, si es necesario.



Enter the SSID and password for the network. Devon Delfino/Business Insider

If you're having trouble connecting to Wi-Fi, you may need to [restart your Chromebook](#), or think about getting a new router if your connection is weak. [Google Wi-Fi](#) offers one of the best connections for a standard home, and will go perfectly with your [Chromebook](#).